



# User's Manual

## JetFlash<sup>®</sup> Vault 100

(2020/03 Version 1.0)



## Table of Content

1. System Requirements .....	3
2. Setting a Password and Hint (Windows) .....	3
3. Start Using JetFlash Vault (Windows) .....	7
4. JetFlash Vault Options (Windows) .....	9
JetFlash Vault settings .....	9
Browse JetFlash Vault .....	10
Formatting JetFlash Vault.....	10
Online support .....	11
About.....	11
Close JetFlash Vault.....	11
5. Setting a Password and Hint (Mac).....	12
6. Start Using JetFlash Vault (Mac).....	15
7. JetFlash Vault Options (Mac).....	17
JetFlash Vault settings .....	17
Browse JetFlash Vault .....	18
Formatting JetFlash Vault.....	18
Online support .....	19
About.....	19
Close JetFlash Vault.....	19
8. Frequently Asked Questions .....	20
9. End-User License Agreement.....	20
10. Eurasian Conformity Mark (EAC).....	20

## 1. System Requirements

**JetFlash® Vault can support the following Operation Systems:**

Windows®7

Windows 8 (Windows 8 RT is not supported)

Windows 8.1

Windows 10

Mac® OS X 10.10 or later


### **Suggestion**

To ensure there is sufficient power provided to JetFlash Vault, you are suggested to insert it directly to a USB 3.0 (or 2.0) port on your desktop or notebook. Avoid connecting JetFlash Vault to devices that feature an extra USB port such as USB-powered hub or keyboard.

## 2. Setting a Password and Hint (Windows)

Before using your JetFlash Vault, you are advised to set a password and hint to protect your data on the JetFlash Vault.

1. Insert the JetFlash Vault into an available USB port on your notebook or desktop.
2. Open File Explorer and click **DVD RW JetFlash Vault** on the left. Then double-click **JetFlashVault\_Launcher** to launch JetFlash Vault.



<input type="checkbox"/> Name	Date modified	Type	Size
Files Currently on the Disc (3)			
JetFlashVault.app	1/19/2017 5:18 PM	File folder	
autorun.inf	1/5/2017 2:55 PM	Setup Information	1 KB
<input checked="" type="checkbox"/> JetFlashVault_Launcher.exe	1/19/2017 5:18 PM	Application	1,027 KB





3. Set a password and re-enter your password.

**Note:** Password needs to be at least 6 characters and include 3 of the following characters: Upper case letters, lower case letters, digits and special characters.

**Warning!** Please remember your password well. For security reason, if you forget your password, you will have to format the device before next use.


**Formatting the device will erase all data stored on JetFlash Vault.**

Please set a password



New password

Check password



 Password rule

Hint

4. Set a Hint (Optional). The hint can be helpful in providing a clue in case you forget your password. Click **OK** to finish password and hint setting.


**Note:** The hint cannot be too similar to your password.

Please set a password



New password

Check password

 Password rule

Hint

5. Click **Finish** to complete password and hint setting.

Please set a password



New password

Check password


 Password rule

Hint

Settings completed! You can start using JetFlash Vault now.

### 3. Start Using JetFlash Vault (Windows)

1. Insert the JetFlash Vault into an available USB port on your notebook or desktop.
2. Open File Explorer and click **DVD RW JetFlash Vault** on the left. Then double-click **JetFlashVault\_Launcher** to launch JetFlash Vault.





3. Enter your password, then click **Login**.

**Warning!** The preset maximum incorrect login attempt is 10. If you reach the limit, you must format your JetFlash Vault and reset a password.

**Formatting the device will erase all data stored on JetFlash Vault.**

- Click **Forget Password** to format your JetFlash Vault and set a new password.
- Click **Hint** to show the hint you set.
- You can set your **Contact Information** in [JetFlash Vault settings](#)
- Check the **Read Only** box if you want to use JetFlash Vault in Read-only mode. In Read-only mode, you can only view files, but not format JetFlash Vault, update, change or delete any content.

Login



Please enter password

[Forget password](#) | [Hint](#) | [Contact information](#)


Read Only

4. Once logged in, you will be able to use JetFlash Vault.



## 4. JetFlash Vault Options (Windows)


Once logged in JetFlash Vault, first click the up-arrow in the right-hand corner of the Windows taskbar, then right-click the JetFlash Vault icon to see the option menu.




- **JetFlash Vault settings**

**Note:** You must enter the current password to set/modify these settings

Password: Modify your password and/or hint



Contact information: Set/view/modify your contact information



Language: Change your current language



- **Browse JetFlash Vault**


Once logged in, you can browse the data you save on JetFlash Vault

- **Formatting JetFlash Vault**

Format your JetFlash Vault.

**Note:** You must enter the current password to set/modify these settings

**Warning!** All data will be erased.




- **Online support**

Link to Transcend official website for additional information and support.

- **About**

Display details of your JetFlash Vault, including Module, Firmware Version information.




- **Close JetFlash Vault**

Remove your JetFlash Vault safely from your system.

## 5. Setting a Password and Hint (Mac)

Before using your JetFlash Vault, you are advised to set a password and hint to protect your data on the JetFlash Vault.

1. Insert the JetFlash Vault into an available USB port on your notebook or desktop.
2. Open Finder and click **JetFlash Vault** on the left. Then double-click **JetFlashVault**.





3. Set a password and re-enter your password.

**Note:** Password needs to be at least 6 characters and include 3 of the following characters: Upper case letters, lower case letters, digits and special characters.


**Warning!** Please remember your password well. For security reason, if you forget your password, you will have to format the device before next use.

**Formatting the device will erase all data stored on JetFlash Vault.**

The screenshot shows a software interface for setting a password and hint. At the top, there is a header with the JetFlash VAULT logo and the Transcend logo. Below the header, there are four input fields: 'New password', 'Check password', and 'Hint'. A 'Password rule' button with an information icon is located below the 'Check password' field. At the bottom of the form, there are two buttons: 'OK' and 'Cancel'.


4. Set a Hint (Optional). The hint can be helpful in providing a clue in case you forget your password. Click **OK** to finish password and hint setting.

**Note:** The hint cannot be too similar to your password.




The image shows a software dialog box for setting a password. At the top left is a logo for 'JetFlash VAULT The Safest Safe' and at the top right is the 'Transcend' logo. The dialog contains three input fields: 'New password' with ten dots, 'Check password' with ten dots, and 'Hint' with the text 'Ex: favorite color + number'. Below the 'Check password' field is a 'Password rule' button with an information icon. At the bottom are 'OK' and 'Cancel' buttons.

5. Click **Finish** to complete password and hint setting.



## 6. Start Using JetFlash Vault (Mac)

1. Insert the JetFlash Vault into an available USB port on your notebook or desktop.
2. Open Finder and click **JetFlash Vault** on the left. Then double-click **JetFlashVault**.




3. Enter your password, then click **Login**.

**Warning!** The preset maximum incorrect login attempt is 10. If you reach the limit, you must format your JetFlash Vault and reset a password.

**Formatting the device will erase all data stored on JetFlash Vault.**

- Click **Forget Password** to format your JetFlash Vault and set a new password.
- Click **Hint** to show the hint you set.

- You can set your **Contact Information** in [JetFlash Vault settings](#)
- Check the **Read Only** box if you want to use JetFlash Vault in Read-only mode. In Read-only mode, you can only view files, but not format JetFlash Vault, update, change or delete any content.



JetFlash® VAULT  
The Safest Safe

Transcend®

Password

[Forget password](#)   [Hint](#)   [Contact information](#)

Read Only

[Login](#)   [Cancel](#)

4. Once logged in, you will be able to use JetFlash Vault.



## 7. JetFlash Vault Options (Mac)


Once logged in JetFlash Vault, click the JetFlash Vault icon in the top right-hand corner to see the option menu.




- **JetFlash Vault settings**

**Note:** You must enter the current password to set/modify these settings


Password: Modify your password and/or hint



Contact information: Set/view/modify your contact information



Language: Change your current language



- **Browse JetFlash Vault**


Once logged in, you can browse the data you save on JetFlash Vault

- **Formatting JetFlash Vault**

Format your JetFlash Vault.

**Note:** You must enter the current password to set/modify these settings

**Warning!** All data will be erased.




- **Online support**

Link to Transcend official website

([www.transcend-info.com/supports/service.aspx](http://www.transcend-info.com/supports/service.aspx)) for additional information and support.

- **About**

Display details of your JetFlash Vault, including Module, Firmware Version information.



- **Close JetFlash Vault**

Remove your JetFlash Vault safely from your system.

## 8. Frequently Asked Questions

Please visit Transcend website [www.transcend-info.com/Support/No-770](http://www.transcend-info.com/Support/No-770) for FAQs. If you still cannot find the answer to your problem, please visit our Tech Support website at [www.transcend-info.com/Support/contact\\_form](http://www.transcend-info.com/Support/contact_form)

## 9. End-User License Agreement

Please visit Transcend website [www.transcend-info.com/Legal/?no=5](http://www.transcend-info.com/Legal/?no=5) for End-User License Agreement.

## 10. Eurasian Conformity Mark (EAC)

